

## Configuring a Sony Ericsson W760 for MMS and Browser with a Solo SIM Card on the HSPA+ network

The following instructions can be used to manually configure the settings on an unlocked Sony Ericsson W760 phone for MMS and Browser with a Solo SIM Card.

1. Follow the instructions in the user manual to install your Solo SIM Card into the phone.
2. Power on the phone.

### Browser settings

1. From the standby screen, select **Menu > Settings > Connectivity** (navigate right to this tab) > **Internet settings**.
2. Select **Connect using**.
3. Press **Options** (left soft key), and select **Create new**.
4. Select **PS data**.
5. Enter the following settings information in each of the fields:  
**Name:** Bell WAP Connection (can be anything)  
**APN:** pda.bell.ca
6. Press **Save** (left soft key).
7. With the newly created name (Bell WAP Connection) highlighted, press **Options** (left soft key).
8. Select **Edit**.
9. Scroll down and select **Proxy settings**.
10. Select **Proxy** and set to **On**.
11. Scroll down and select **Proxy servers**.
12. Select **HTTP** and enter and save the following settings information in each of the fields:  
**Username:** <leave blank>  
**Password:** <leave blank>  
**Proxy address:** web.wireless.bell.ca  
**Port:** 80
13. Navigate back to the **Data account** screen, scroll and highlight the name you created above (Bell WAP Connection). Press **Select** (middle soft key), and then press **Save** (left soft key).

### MMS settings

1. From the standby screen, select **Menu > Settings > Connectivity** (navigate right to this tab) > **Internet settings**.
14. Select **Connect using**.
15. Press **Options** (left soft key), and select **Create new**.
16. Select **PS data**.
17. Enter the following settings information in each of the fields:  
**Name:** Bell MMS Connection (can be anything)  
**APN:** pda.bell.ca
18. Press **Save** (left soft key).
19. With the newly added account name highlighted, press **Options** (left soft key).
20. Select **Edit**.
21. Scroll down and select **Authentication**. Select (mark) **PAP**, and deselect (unmark) all other options. Press **Save** (left soft key).
22. Scroll down and select **Proxy settings**.
23. Select **Proxy** and set to **On**.
24. Scroll down and select **Proxy servers**.
25. Select **HTTP** and enter and save the following settings information in each of the fields:  
**Username:** <leave blank>  
**Password:** <leave blank>

**Proxy address:** web.wireless.bell.ca

**Port:** 80

26. Go back to the previous screen and apply the settings for HTTP to **Secure** and **Streaming**.
27. Press **Back** to save the settings and return to the main screen.
28. Navigate to **Menu > Messages > Settings > Picture message > MMS Profile**.
29. Scroll to **New Profile** and press **Add** (middle soft key).
30. Enter the following settings information in each of the fields:
  - MMS profile name:** Bell MMS Profile (can be anything)
  - Message server:** http://mms.bell.ca/mms/wapenc
  - Connect using:** Bell MMS Connection (created above)
31. Press **Save** (left soft key).
32. Scroll and highlight the MMS profile name that you just created (Bell MMS Profile), and press **Select** (middle key).